

Addendum

Overdrive Off Switch

Workhorse Chassis

2006 Monarch[®] SE
2006 LaPalma[®]



The information printed here reflects product design, fabrication, and component parts at the date of printing. The manufacturer reserves the right, at any time, to make changes in product design or material or component specifications as its sole option, without notice. This includes the substitution of components of a different brand or trade name, which will result in comparable performance. All information printed in this document is subject to change after the date of printing. Due to product improvements, changes during the model year and/or transcription errors that may occur, information represented within the owner's manual and/or this document may not be accurate at the time of your purchase. Please confirm any information with your dealer.

©Monaco Coach Corporation. All rights reserved. Monarch[®] SE and LaPalma[®] are registered trademarks of Monaco Coach Corporation. All other trademarks or registered trademarks are property of their respective holders. Brand name products of other companies mentioned in this addendum are not endorsed by Monaco Coach Corporation.

The following information applies to 2006 Monarch® SE and LaPalma® models equipped with 20,700 lb, 22,000 lb or 24,000 lb Workhorse Chassis. These chassis are optional on some models.

Overdrive Off Switch:

The “Overdrive Off” switch is located to the left of the steering wheel on the dash. This is a three-position switch that controls overdrive selection on the 6-speed transmission. Overdrive is engaged when the switch is in the bottom position. The center position will lock the transmission out of 6th gear. The top position will lock the transmission out of 5th and 6th gear. Recommended use of the overdrive switch is noted below.

- The transmission should be able to maintain 6th gear on fairly level roads. The “Overdrive Off” switch should be in the bottom position so that overdrive is engaged.
- The transmission should be in 5th gear on undulating to moderate grades. The “Overdrive Off” switch should be in the middle position to select 5th gear and lock the transmission out of 6th gear.
- Overdrive off can be selected for steep grades or when towing heavy loads. The “Overdrive Off” switch should be in the top position. This allows the transmission to upshift to 4th gear and lock the transmission out of overdrive (5th and 6th gears).

NOTE:

See the Workhorse chassis manual for additional information.



080514

Overdrive Off Switch



MONACO®

Monaco Coach Corporation

91320 Coburg Industrial Way

Coburg, OR 97408

800-634-0855

www.monaco-online.com

Warranty/Technical Support

Toll Free 877-466-6226