

***Rear View System***

---

***2005***

---

***LaPalma***

The information printed here reflects product design, fabrication, and component parts at the date of printing. The manufacturer reserves the right, at any time, to make changes in product design or material or component specifications as its sole option, without notice. This includes the substitution of components of a different brand or trade name, which will result in comparable performance. All information printed in this document is subject to change after the date of printing. Due to product improvements, changes during the model year and/or transcription errors that may occur, information represented within the owner's manual and/or this document may not be accurate at the time of your purchase. Please confirm any information with your dealer.

The following information is in addition to the information published in the 2005 LaPalma Owner's Manual in Section 2 (Driving & Safety) page 39. Please utilize the information provided henceforth.

**©Monaco Coach Corporation. All rights reserved. All other trademarks or registered trademarks are property of their respective holders. Brand name products of other companies mentioned in this addendum are not endorsed by Monaco Coach Corporation.**


## REAR VIEW SYSTEM

The motorhome is equipped with a rear vision and voice system. The rear vision system consists of an adjustable camera with a microphone and a dash mounted monitor. This allows the driver to see what is behind the motorhome and listen to verbal guidance.

### Monitor Features:

- **Power ON/OFF** button: Turning the main power switch ON will allow continuous operation of the rear vision system while the ignition key is ON.
- **Camera Manual/Auto** button:(Optional three camera system only.) With the button in the Manual (out) position, any of the three cameras can be selected with the red toggle switch at the bottom of the monitor. With the button in the Auto (in) position, the camera will automatically change views with blinker activation.
- **Day/Night** button: Set camera for better picture in varying light conditions.
- **Contrast** and **Brightness** knobs.
- **Volume** control knob.
- **Camera Select** switch: Keep switch in the “Rear” position to adjust camera angle.
- **Up** and **Down** buttons: To adjust rear camera angle. Optional Side cameras are not adjustable.
- **Defog** button: Works for rear camera only. Defog turns off automatically after a preset temperature is reached.

**INFORMATION:** For more detailed instructions, see the manufacturer’s manual.



031156



**Monaco Coach Corporation**

91320 Coburg Industrial Way

Coburg, OR 97408

800-634-0855

[www.monacocoach.com](http://www.monacocoach.com)

**Warranty/Technical Support**

Toll Free 877-466-6226