

# Battery Cut-off

## 2008 Signature Series



The information printed here reflects product design, fabrication, and component parts at the date of printing. The manufacturer reserves the right, at any time, to make changes in product design or material or component specifications as its sole option, without notice. This includes the substitution of components of a different brand or trade name, which will result in comparable performance. All information printed in this document is subject to change after the date of printing. Due to product improvements, changes during the model year and/or transcription errors that may occur, information represented within the owner's manual and/or this document may not be accurate at the time of your purchase. Please confirm any information with your dealer.


The following information supercedes previous information and applies to certain model motorhomes equipped with a Roadmaster Chassis.

©Monaco Coach Corporation. All rights reserved. All other trademarks or registered trademarks are property of their respective holders. Brand name products of other companies mentioned in this addendum are not endorsed by Monaco Coach Corporation.

The following information supersedes the information printed in the 2008 Signature Owner's Manual, in Section 8 – House Electrical, on page 175 under the “Battery Cut-Off” heading.

## BATTERY CUT-OFF

The battery cut-off switch is located inside the motorhome next to the entry door. This switch controls 12 Volt DC power to the domestic fuse panel and house Multiplex System. Power is supplied to all interior DC lighting and DC operated appliances when the switch is activated. Some appliances will require both DC and AC power to operate, such as the roof air conditioner. This switch is helpful when dry camping to conserve house battery power.



080527

- ◆ Press and release the battery cut-off switch to turn on interior 12 Volt DC house power.
- ◆ Press and hold the switch for two seconds to turn off interior 12 Volt DC house power. The two second delay will help to prevent accidentally turning off house power.

Refrigerator and inverter operation are unaffected by the use of this switch. When the interior house power is off there are still parasitic loads on the house batteries; therefore, it is not a substitute for the main battery disconnect switch.

### **CAUTION:**

**Avoid flash damage to electrical contacts. Turn off the interior lighting before operating the battery cut-off switch.**

**Monaco Coach Corporation  
91320 Coburg Industrial Way  
Coburg, OR 97408  
800-634-0855  
[www.monaco-online.com](http://www.monaco-online.com)**

**Warranty/Technical Support  
Toll Free 877-466-6226**